



M02288	POSITIONS A, E AND F :
M02429	10 BUSHINGS TOTAL
S10125	
M02348	POSITIONS B, C, AND D :
M02350	12 BUSHINGS TOTAL
S10125	

- BODY MOUNT INSTRUCTIONS 97-02 JEEP TJ WRANGLER**
- 1) MAKE SURE ENGINE AND RADIATOR ARE BOTH COOL.
 - 2) SPRAY EXISTING BODY MOUNT BOLTS WITH LUBRICANT/RUST REMOVER
 - 3) DISCONNECT OVERFLOW HOSE FROM THE RADIATOR AND REMOVE OVERFLOW TANK.
 - 4) REMOVE FOUR (4) BOLTS FROM THE FAN SHROUD AND MOVE SHROUD TOWARDS THE ENGINE.
 - 5) LOOSEN ONE (1) SIDE OF EXISTING BODY MOUNTS THEN REMOVE BOLTS FROM THE OPPOSITE SIDE.
 - 6) WHEN JACKING THE BODY, USE A LONG 2X4 OR 4X4 FOR SUPPORT. NEVER PUT JACK DIRECTLY ON BODY PANELS.
 - 7) SLOWLY JACK BODY UP, CHECKING THE FAN AND 4-WHEEL DRIVE SHIFT LINKAGE FOR SUFFICIENT CLEARANCE.
 - 8) REMOVE THE OLD MOUNTS AND REPLACE WITH THE NEW MOUNTS. REINSTALL BOLTS BUT DO NOT TIGHTEN.
 - 9) REPEAT STEP 8 FOR THE OPPOSITE SIDE, WHILE CONTINUING TO CHECK FOR CLEARANCE.
 - 10) DO NOT TIGHTEN BOLTS UNTIL ALL 12 BODY MOUNTS ARE REPLACED.
- NOTE: AFTER 2 WEEKS OF USE RETORQUE ALL BOLTS TO FACTORY SPECIFICATIONS.*