

1. PLASTIC RADIATOR FAN SHROUD: Only raise body high enough to remove and replace body mounts. Always watch the fan shroud for sufficient clearance when raising the body.
2. Loosen body mount bolts on one side of vehicle and remove bolts from opposite side for positions 1,2 and 3, See Fig.2. Place a 2x4 between jack and body to spread out load and jack up body on the side you have removed the bolts from just far enough to remove mounts. The bolts on the opposite side will help ensure that the body does not shift.
3. Remove factory mounts one at a time.
4. Install the new S10321 steel bracket, polyurethane body mounts, and steel sleeves in positions 2 and 3. Refer to the Bill of materials for positions.
5. Start the stock bolts into the new mounts.
6. Now remove bolts from other side of vehicle and repeat steps 3 through 5.
7. Once all new mounts are in place, you may re-torque all bolts to factory specs. Do not over tighten bolts.
8. Before starting engine, check fan for clearance from fan shroud and make sure all lines and wires are free and clear.

Bill of Materials				
Fig. 1. Assembly Orientation	Fig. 2. Mounting Position 1		Fig. 2. Mounting Positions 2 & 3	
Location #	Description	Qty.	Description	Qty.
1	Stock Bolt	2	Stock Bolt	4
2	Body	N/A	Body	N/A
3	S10125 Washer 2		S10126 Washer 4	
4	M03358	2	M03357	4
5	Frame	N/A	S10321	4
6	M02850	2	M02845	4
7	S10555	2	S10276	4
8	S10125 Washer 2		Stock Washer	

Figure 1.





Figure 2.

WARNING

This vehicle has been modified to enhance its performance. The steering, braking and handling of this vehicle will differ from standard passenger cars and trucks. This vehicle handles differently from an ordinary vehicle in driving conditions which may occur on streets, highways and off road. Avoid unnecessary abrupt maneuvers, sudden stops, sharp turns and other driving conditions that could cause loss of control, possibly leading to a roll over or other accident that could result in serious injury or death to driver and passengers. If larger tires are installed the speedometer will read lower than the vehicles actual speed.

DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

This kit should be installed by a professional mechanic.